

AttackPRO™
TruckCHARGER™
DRILLING TEMPLATE

TOP EDGE

LEFT EDGE

Middle Attachment Point

IMPORTANT: Pilot holes must be drilled using a 1/8" (0.125 inches) drill bit.



Left Attachment Point

IMPORTANT: Pilot holes must be drilled using a 1/8" (0.125 inches) drill bit.



Right Attachment Point

IMPORTANT: Pilot holes must be drilled using a 1/8" (0.125 inches) drill bit.



NOTE: This template is scaled 1:1 with the AttackPRO Truck Charger. The bottom edge of the device is not shown here.